





D Laifual Drive



Address: Ganlin Industrial Zone, Shengzhou, Zhejiang, China Tel:86-575-83272870 Fax:86-575-83272888 E-mail:info@laifual.com Service:service@laifual.com



Address: Kangyang building, Huangdai Town, Xiangcheng District, Suzhou City, Jiangsu, China Tel:86-512-67236762 Fax:86-575-81388192



ZHEJIANG LAIFUAL DRIVE CO.,LTD

Product photos

LSS SERIES



LSS/LSN/LSG



LSS-I-M



LFS- I



LSD

LHT SERIES



LHT/LHG- I



LHT/LHG- II



LHT/LHN/LHG-III



LHT/LHN/LHG-IV



LHT/LHG- V



LHD- I



LHD-III

CONTENTS

Principle of harmonic gear reducer	
Company presentation	
Technical information	Tooth profile About grease Terms and definitions Wave generator Installation procedure Assembly considerations Installation precautions Specification of main bearing Moment load table
LSS series	LSS series Rated parameter table of LSS/LSN series Rated parameter table of LSG series LSS/LSN/LSG-I series Size chart LSS/LSN/LSG-II series Size charts Rated parameter table of LSD series LSD-I series Rated parameter table of LFS series LFS-I series
LHT series	LHT series Rated parameter table of LHT/LHN series Rated parameter table of LHG series LHT/LHG-I Size chart LHT/LHG-II Size chart LHT/LHN/LHG-III Size chart LHT/LHN/LHG-IV Size chart LHT/LHG-V Size chart Rated parameter table of LHD series LHD-I size chart LHD-III size chart
Others	Warranty Trademark Certification Application Safety precautions

43

13

16 17

21

22

24 25

26 27 27

Principle of harmonic gear reducer

I. Composition of harmonic gear reducer

Harmonic gear reducer has three basic components:a wave generator,a flexspline and a circular spline.

Wave generator: it is made up of a ball bearing and an elliptical cam. The wave generator is usually attached to the input end, the inner ring of the bearing is fixed around the cam causing the outer ring of the bearing deforms to an elliptical shape.

Fexspline: it is an elastic thin-walled component with gear teeth on outer surface. It is usually fitted to output end.

Circular spline:it is a rigid steel ring with internal teeth. It usually has two more teeth than the flexspline, and generally mounted onto a housing.

II. Principle of harmonic gear reducer


As a reducer, the harmonic gear reducer is often in a status as:the wave generator drives, the circular spline is fixed, the flexspline is output end.

When the wave generator is put inside of the flexspline, the flexspline is forced into an elliptical shape causing the flexspline teeth to engage with the tooth profile of the circular spline along the major axis of the ellipse, with the teeth completely disengaged across the minor axis of the ellipse.


The rotation of the wave generator makes the flexspline deform continuously, the teeth change operating state in the process of engagement and disengagement, thus the motion transmission between wave generator and flexspline is realized.

III .Characteristics of harmonic gear reducer

- 1. High accuracy: a good percentage of its teeth are meshed at all times, and are engaged at two zones 180 degrees apart. This means influences of tooth pitch errors and accumulated pitch errors on rotational accuracy are neutralized, which assures high positional and rotational accuracy.
- 2. High speed reduction ratio: a harmonic gear reducer has high single-stage reduction ratios of 1/30-1/500. Three basic components along same axle without complex structures can provide high reduction ratios.
- 3. High torque capacity:each tooth is subjected to a negligible amount of force yet provides a high torque capacity because of the way the teeth come into contact with each other and because a good percentage of the teeth in the flexspline are engaged at all times.
- 4. Small-sized and light weight: while being less the size of conventional gearing mechanisms and less the weight, the harmonic gear reducer provides the same levels of torque and speed reduction ratios as its conventional counterparts enabling machinery and equipment to be made smaller and lighter.
- 5. Superior efficiency and long life time.
- 6. Quiet and minimal vibration operation.




The flexspline is forced into an elliptical shape by the wave generator causing the flexspline teeth to engage with the tooth profile of the circular spline along the major axis of the ellipse, with the teeth completely disengaged across the minor axis of the ellipse



As the wave generator rotates clockwise with the circular spline fixed, the flexspline is subjected to elastic deformation and its tooth engagement position moves turning relative to the circular spline.



As the wave generator rotates 180 degrees clockwise, the flexspline moves counterclockwise by one tooth relative to the circular spline.



For every one full rotation clockwise (360 degrees) of the wave generator, the flexspline moves counterclockwise by two teeth relative to the circular spline because the flexspline has two fewer teeth than there are on the circular spline. In general, this movement is treated as output performing.



D Laifual Drive

Company presentation

Zhejiang Laifual Drive Co., Ltd is a national high-tech enterprise, mainly engaged in research and manufacture of high-precision harmonic reducers and planetary gear reducers. Total factory is 30,000 square meters. About 300 employees, including around 30 R&D Personnel, with more than 10 years experience in research and development.

Laifual uses the world's first class production and inspection equipment. Pay attention to every production details, we have very strict quality control from raw materials to the finished products, to make sure the excellent quality of all products. All products are completely developed by ourselves, Laifual's R&D center is recognized as "High-tech enterprise R&D center in Zhejiang province".

After years of hard working, Laifual has obtained 30 patents in the field of drive area. Including 1 major scientific and technological patent and 29 independent intellectual property rights patents. Laifual was recognized as a national high-tech enterprise, medium-sized enterprise in Zhejiang province, and successfully passed the ISO9001 quality management system certification.

Thanks to years of research and development experience, Laifual has made breakthroughs in many special performance. Our high precision harmonic reducer have the characteristics of low temperature rise, low starting torque, high reliability, big torque, long life time, big speed ratio, small size, etc. Which can be widely used in industrial robots, service robots, medical equipment, high precision automation equipment, etc. And we sincerely provide satisfactory and diversified custom design services for all our valued customers.

Taking professionalization, internationalization as standard, to build Laifual into the most respectable harmonic reducer brand.

Technical Information


Tooth profile	5
About grease	6
Terms and definitions	7
Wave generator	8
Installation procedure	9
Assembly considerations	11
Installation precautions	12
Specification of main bearing	13
Moment load table	14


Tooth profile

- Gear toothing capacity increased by 15%
- Reduce gear fatigue pitting contact area
- Temperature rise decreased by 8-10 degrees
- Service time over 15000 hours

About LS tooth profile

We have made some upgrades based on the traditional theoretical double arc profile. The tooth profile formed by the original two-curve continuous arc curve is optimized as a continuous arc curve with multiple segments of curvature. To ensure that the gears of reducer are properly meshed, while protecting the risk of grease failure after grease is squeezed by reducing relative sliding friction. Based on the δ tooth shape, the load capacity is increased by 15%, the temperature rise is reduced by 8-10 degrees, the gear fatigue pitting contact area is reduced by more than 30%, continuous running and service life is over 15000 hours, which improves the overall performance of the harmonic reducer.





During development, the formation of the soft tooth profile can be determined by the radial displacement of the generator. Different gear reduction ratios can be fitted with various tooth profiles. And the mesh backlash can be conveniently adjusted according to actual conditions. Keep the reducer in the best working condition.

About grease

Special grease developed for laifual drive

Laifual's LF-I grease

Compare with the common greases on the market, Laifual's grease has high efficiency and durable.

Laifual's LF-II grease

Excellent lubrication when the wave generator is rotated by extruding additives to liquefy.

Grease characteristics

Model	Color	Operating temperature	Working ambient temperature	Durability	Grease leakage
LF-I	YELLOW	0°C~+40°C	-20°C~+100°C	0	©
LF-II	GREEN	0°C~+40°C	-20°C~+100°C	0	0

[○] Applicable ⑤ Superior

A suitable grease for different models

Greases for reduction ratio more than 50

Reduction ratio Model	Reduction ratio	11	14	17	20	25	32	40
Grease	LF-I	_	_	_	0	0	0	0
	LF-II	0	0	0				

[○] Standard grease □ Quasi-standard grease

Seal size description

Series	Model	Circul	ar spline	Flexspline		
Series	Model	Seal size	Slot size	Seal size	Slot size	
	14	37 * 1	$\Phi 37_{-0.1}^{-0} * \phi 39.6_{0}^{+0.1} * 0.75_{0}^{+0.1}$	53 * 1.5	$\phi 53_{\tiny{-0.1}}^{\tiny{-0.1}} * \ \phi 56.8_{\tiny{0}}^{\tiny{+0.1}} * 1.15_{\tiny{0}}^{\tiny{+0.1}}$	
LHT-I	17	46.5 * 1	$\phi 46.5_{\scriptscriptstyle{0.1}}^{\scriptscriptstyle{0.0}} * \phi 49.1_{\scriptscriptstyle{0}}^{\scriptscriptstyle{+0.1}} * 0.75_{\scriptscriptstyle{0}}^{\scriptscriptstyle{+0.1}}$	64 * 1	$\phi 64_{ \tiny{+0.1}}^{ \tiny{0.1}} \! \star \phi 66.6_{ \tiny{0.1}}^{ \tiny{+0.1}} \! \star \! 0.75_{ \tiny{0.1}}^{ \tiny{+0.1}}$	
	20	55 * 1	$\phi 55_{-0.1}^{-0} * \phi 57.6_{-0.1}^{+0.1} * 0.75_{-0.1}^{+0.1}$	73 * 1.5	$\phi73_{ {}^{-0.1}}^{ 0.1}\! *\; \phi76.8_{ 0}^{ {}^{+0.1}}\! *1.15_{ 0}^{ {}^{+0.1}}$	
LHT-II	25	68 * 1	$\phi 68_{-0.1}^{-0} * \phi 70.6_{-0.1}^{+0.1} * 0.75_{-0.1}^{+0.1}$	90 * 1.5	$\phi 90_{-0.1}^{-0.1} \!$	
	32	88 *1.5	φ88 _{-0.1} * φ92 ^{+0.1} * 1.15 ^{+0.1}	119 * 1.5	$\phi 119_{\tiny{0.1}}^{\tiny{0.1}} * \phi 123.1_{\tiny{0}}^{\tiny{0.1}} * 1.15_{\tiny{0}}^{\tiny{0.1}}$	

Terms and definitions

Starting torque

It is the minimum torque value applied to the input end at which the harmonic reducer first starts to rotate with no load.

Backlash

The clearance between flexspline tooth profile and circular spline tooth profile.

Rated torque

It indicates allowable continuous output torque at rated input speed.

Permissible peak torque at start and stop

It's the maximum torque as a result of the moment of inertia of the output load during acceleration and deceleration.

Permissible maximum value for average load torque

It's the maximum torque when the harmonic reducer keeps continuous operation.

Permissible maximum momentary torque

It is the momentary peak torque the harmonic reducer may be subjected to the event of a collision or emergency stop.

Permissible maximum input rotational speed

Don't exceed the permissible rating.


Permissible average input rotational speed

It's the average value of input speed.


Wave generator

The wave generator includes a structure of a European-style coupling with a self-aligning structure and an integrated type without an automatic self-aligning structure, and varies depending on the series. For details, please refer to the outline drawing of

• Basic structure and shape of wave generator shown as below:



· Structure of cross sliding block type-Using European coupling structure



- Holder of flexible bearing
- Gasket
- Plexible baring
- Ring-shield
- 3 Wave generator
- Power input shaft
- Cross sliding block

Axial force and axial fixation of wave generator

The axial force on wave generator begins to work due to elastic deformation of flexspline.


When used as a reducer, the axial force moves towards to the inside of the flexspline.

When used as a speed increaser, the axial force's movement is opposite to the direction of the deceleration.

The design of prevent axial force of wave generator shall be adopted under any conditions of usage.

*Please make sure to consult with the authorized distributor when setting the stop screw and fixing it to the input axial on the wave

· Axial force direction of the wave generator




Maximum aperture size of the unibody wave generator

The standard aperture of the wave generator has shown in the outlinedrawing, the alteration can be made within maximum size range shown

We suggest to use GB standard for keyway size. The key's effective length dimension should be designed to fully withstand the value of the transmitted torque.


Wave generator aperture								
Model	11	14	17	20	25	32	40	
Standard size (H7)	6	6	8	8	14	14	14	
Minimum size	3	3	4	5	6	6	10	
Maximum size	8	17	20	23	28	36	42	

The aperture of the wave generator can be customized according to customer requirements Please contact with the authorized distributor in case of any changes in the table.




Installation procedure


Installation of LSS series



The first method of installation for LHT-I/II Series



The second method of installation for LHT-I/II series



Installation procedure


The connecting and fixing method of wave generator

Flat gasket


1. Input shaft has a shaft shoulder, it can be connected with wave generator directly. As shown in the figure.

2.Input shaft has a shaft shoulder, but it's too long. You can add a space ring on the shaft(the parallelism of space ring should be within 0.01mm), then connect and fix with the wave generator. As shown in the figure.

3.Input shaft has no shaft shoulder. Fix a connection gasket on the wave generator, then connect and fix with the input shaft. As shown in the figure.



4. This fixing method is suitable for small models, optical axis input. Input shaft inserted into the wave generator, then connect and fix it through the thimble screw on wave generator. As shown in the figure.




Wave generator

Assembly considerations

Assembly procedure

Install the circular spline and flexspline on the device, and then install the wave generator, Otherwise it may cause stuffing damage to the gear teeth or improper eccentric gear mesh, Please pay close attention to it,

· Correct assembly steps



Precautions on installation

The improper assembly may cause vibration and noise during operation.

Please assembly base on the following precautions.

- · Precautions on wave generator
- 1.Please avoid applying undue force to the bearing on wave generator during assembly. We suggest to rotate the wave generator while inserting, it will ease the process.
- 2. If the wave generator does not have an oldham coupling, extra care must be given to ensure that concentricity and inclination are within the specified limits.
- · Precautions on circular spline
- 1. Mounting surfaces need to have adequate flatness, smoothness, and no distortion.
- 2. Especially in the area of the screw holes, burrs or foreign matter should not be present.
- 3.Please make sure the chamfering and avoidance machining are performed on the housing assembly, to avoid the interference with the circular spline.
- 4. The circular spline should be rotatable within the housing. Be sure there is no interference and it does not catch on anything.
- 5. When mounting the bolt, make sure the bolt hole is correct and aligned. Bolts should rotate freely when tightening and should not have any irregularity due to the bolt hole being misaligned or oblique.
- 6.Don't tighten the bolts with the specified torque all at once. Tighten the bolts temporarily with about half the specified torque, and then tighten them with the specified torque. Tighten them in an even, crisscross pattern.
- 7. Avoid pinning the circular spline if possible as it can reduce the rotational precision and smoothness of operation.
- Precautions on flexspline
- 1. Mounting surfaces need to have adequate flatness, smoothness, and no distortion.
- 2. Especially in the area of the screw holes, burrs or foreign matter should not be present.
- 3.Please make sure the chamfering and avoidance machining are performed on the housing assembly, to avoid the interference with the circular spline.
- 4. When mounting the bolt, make sure the bolt hole is correct and aligned. Bolts should rotate freely when tightening and should not have any irregularity due to the bolt hole being misaligned or oblique.
- 5.Don't tighten the bolts with the specified torque all at once. Tighten the bolts temporarily with about half the specified torque, and then tighten them with the specified torque. Tighten them in an even, crisscross pattern.
- 6. Avoid unilateral meshing and deviation when assembling with circular spline.
- Rust prevention

The complete assembly unit has no rust prevention on surface.


Please daub anti-rust if needed.

Besides, if an anti-rust product is needed, please contact with the authorized distributor.

Precautions on installation

Assembly accuracy of LSS series

To make sure LSS series play its excellent performance when assemble, please make sure to use the following accuracy.




Recommended accuracy of the assembled housing

Symbol / Model 14 17 20 25 32 a 0.011 0.015 0.017 0.024 0.026 b 0.017 0.020 0.020 0.024 0.024 (0.008) (0.010) (0.010) (0.012) (0.012) c 0.030 0.034 0.044 0.047 0.050 (0.016) (0.018) (0.019) (0.022) (0.022)	Treadministrated detailed of the assembled flousing									
b 0.017 0.020 0.020 0.024 0.024 (0.008) (0.010) (0.010) (0.012) (0.012) (0.012) (0.030 0.034 0.044 0.047 0.050		Symbol / Model	14	17	20	25	32			
(0.008) (0.010) (0.010) (0.012) (0.012) 0.030 0.034 0.044 0.047 0.050		а	0.011	0.015	0.017	0.024	0.026			
(0.008) (0.010) (0.010) (0.012) (0.012) 0.030 0.034 0.044 0.047 0.050		h	0.017	0.020	0.020	0.024	0.024			
C		b	(800.0)	(0.010)	(0.010)	(0.012)	(0.012)			
(0.016) (0.018) (0.019) (0.022) (0.022)		0	0.030	0.034	0.044	0.047	0.050			
		C	(0.016)	(0.018)	(0.019)	(0.022)	(0.022)			

*b.c is the value of the unibody generator (I series) and the cross slider generator (II series). The value in () is the value of the unibody generator (I series).

Assembly accuracy of LHT series

To make sure LHT-I/II series play its excellent performance when assemble, please make sure to use the following accuracy.



· Recommended accuracy of the assembled housing

	-		_			unit: mm
Symbol / Model	14	17	20	25	32	40
а	0.011	0.015	0.017	0.024	0.026	0.026
b	0.017	0.020	0.020	0.024	0.024	0.032
D	(800.0)	(0.010)	(0.010)	(0.012)	(0.012)	(0.012)
С	0.030	0.034	0.044	0.047	0.047	0.050
C	(0.016)	(0.018)	(0.019)	(0.022)	(0.022)	(0.024)

*b.c is the value of the unibody generator (I series) and the cross slider generator (II series). The value in () is the value of the unibody generator (I series).

Specification of main bearing

Each product is assembled with precise cross roller bearing for supporting external loading(Output flange).

Specification of LSS series

		Basic ra	ated load	Allancable			
Туре	Basic rated	dynamic load Cr	Basic rated	static load Cr	Allowable s	Weight	
	KN	kgf	KN	KN kgf		kgfm	kg
14	4.7	480	6.07	620	41	4.2	0.22
17	5.2	540	7.55	770	64	6.5	0.3
20	5.8	590	9.0	920	91	9.3	0.38
25	9.6	980	15.1	1540	156	16	0.6
32	15	1530	25.1	2550	313	32	1.1

- Basic rated dynamic load refers to static radial load that makes dynamic rated life of bearing reach up to 1 million rotations.
- Basic rated static load refers to static load that exerts a certain level of contact stress(4KN/mm) on the central location between rotor of bearing maximum load and contact part of pathway.

 Allowable static moment refers to the value of the maximum torque exerting on output bearing, within the scope of which, it's workable and the basic performance is possible.

Starting torque of LSS series

Reduction ratio Type	11	14	17	20	25	32
50	2.0	4.1	6.1	7.8	15	31
80	1.8	2.8	4	4.9	9.2	19
100	1.5	2.5	3.4	4.3	8	18
120	-	2.3	3.1	3.8	7.3	15
160	-	-	-	3.8	-	-

Specification of LHT series

Туре	Basic rated	Basic ra	ated load Basic rated	Allowable sta	Weight		
	KN	kgf	KN	kgf	Nm	kgfm	kg
14	5.8	590	8.6	880	74	7.6	0.39
17	10.4	1060	16.3	1670	124	12.6	0.56
20	14.6	1490	22	2250	187	19.1	0.73
25	21.8	2230	35.8	3660	258	26.3	1.23
32	38.2	3900	65.4	6680	580	59.1	2.54
40	43.3	4410	81.6	8330	849	86.6	7.2

- Basic rated dynamic load refers to static radial load that makes dynamic rated life of bearing reach up to 1 million rotations.

 Basic rated static load refers to static load that exerts a certain level of contact stress(4KN/mm) on the central location between rotor of bearing maximum load and contact part of pathway.

 Allowable static moment refers to the value of the maximum torque exerting on output bearing, within the scope of which, it's workable and the basic performance is possible.

Starting torque of hollow type(LHT-III)

Ctarting torque of honow type (ETTT in)							
Reduction ratio Type	14	17	20	25	32	40	
50	8.8	27	36	56	85	136	
80	7.5	25	33	50	74	117	
100	6.9	24	32	49	72	112	
120	6.9	24	31	48	68	110	
160	-	-	31	-	-	-	

Starting torque of input axial type(I HT-IV)

Ctarting torque	01 111P	at amai t) PO(=::::	• /			unit: cNm
Reduction ratio	Туре	14	17	20	25	32	40
50		5.7	9.7	14	22	41	72
80		4.4	7.2	11	15	29	52
100		3.7	6.5	9.9	14	27	47
120		3.4	6.2	9.3	13	24	44
160		_	_	8.6	-	-	_

Axial input (LHT-IV) timing belt tension torque recommended value

/ Utial Impat (ng bolt tork	sion torquo	10001111110111	aca valac	unit. Nm
Generator load torque	Model	14	17	20	25	32
Maximum	LHT-IV	13	19	25	25	52

Moment load table

Moment load table of LSS(LSG) series

Model	Value	Permissible value at start and stop	Instant permissible value
medel	M b di 20Nm	M b peak 40Nm	M b max 80Nm
		·	
LSS(LSG)-14	F t di 180N	F t peak 320N	F t max 560N
	F a di 180N	F a peak 320N	F a max 560N
	M b di 30Nm	M b peak 60Nm	M b max 120Nm
LSS(LSG)-17	F t di 230N	F t peak 400N	F t max 700N
	F a di 230N	F a peak 400N	F a max 700N
	M b di 42Nm	M b peak 80Nm	M b max 168Nm
LSS(LSG)-20	F t di 270N	F t peak 480N	F t max 830N
	F a di 270N	F a peak 480N	F a max 830N
	M b di 80Nm	M b peak 160Nm	M b max 313Nm
LSS(LSG)-25	F t di 440N	F t peak 770N	F t max 1320N
	F a di 440N	F a peak 770N	F a max 1320N
	M b di 220Nm	M b peak 440Nm	M b max 890Nm
LSS(LSG)-32	F t di 900N	F t peak 1600N	F t max 2700N
	F a di 900N	F a peak 1600N	F a max 2700N

Moment load table of LHT(LHG) series

Model	Value	Permissible value at start and stop	Instant permissible value
	M b di 41Nm	M b peak 80Nm	M b max 160Nm
LHT(LHG)-14	F t di 270N	F t peak 490N	F t max 830N
	F a di 270N	F a peak 490N	F a max 830N
	M b di 72Nm	M b peak 140Nm	M b max 290Nm
LHT(LHG)-17	F t di 400N	F t peak 700N	F t max 1200N
	F a di 400N	F a peak 700N	F a max 1200N
	M b di 140Nm	M b peak 280Nm	M b max 560m
LHT(LHG)-20	F t di 650N	F t peak 1150N	F t max 1980N
	F a di 650N	F a peak 1150N	F a max 1980N
	M b di 243Nm	M b peak 480Nm	M b max 974Nm
LHT(LHG)-25	F t di 900N	F t peak 1600N	F t max 2800N
	F a di 900N	F a peak 1600N	F a max 2800N
1117/1110\ 00	M b di 460Nm	M b peak 900Nm	M b max 1860Nm
LHT(LHG)-32	F t di 1350N	F t peak 2300N	F t max 4000N
	F a di 1350N	F a peak 2300N	F a max 4000N
LHT(LHG)-40	M b di 600Nm	M b peak 1200Nm	M b max 3000Nm
LHT(LHG)-40	F t di 2000N	F t peak 3500N	F t max 6000N
	F a di 2000N	F a peak 3500N	F a max 6000N

[■] Note: Output load Mb- Bending moment, Ft-radial force, Fa-axial force


Moment load table of LSD series

Model	Value	Permissible value at start and stop	Instant permissible value
	M b di 20Nm	M b peak 40Nm	M b max 80Nm
LSD-14	F t di 180N	F t peak 320N	F t max 560N
	F a di 180N	F a peak 320N	F a max 560N
	M b di 30Nm	M b peak 60Nm	M b max 120Nm
LSD-17	F t di 230N	F t peak 400N	F t max 700N
	F a di 230N	F a peak 400N	F a max 700N
	M b di 42Nm	M b peak 80Nm	M b max 168Nm
LSD-20	F t di 270N	F t peak 480N	F t max 830N
	F a di 270N	F a peak 480N	F a max 830N
	M b di 80Nm	M b peak 160Nm	M b max 313Nm
LSD-25	F t di 440N	F t peak 770N	F t max 1320N
	F a di 440N	F a peak 770N	F a max 1320N
1.00.22	M b di 220Nm	M b peak 440Nm	M b max 890Nm
LSD-32	F t di 900N	F t peak 1600N	F t max 2700N
	F a di 900N	F a peak 1600N	F a max 2700N

Moment load table of LHD series


Model	Value	Permissible value at start and stop	Instant permissible value
	M b di 41Nm	M b peak 80Nm	M b max 160Nm
LHD-14	F t di 270N	Ft peak 490N	F t max 830N
	F a di 270N	F a peak 490N	F a max 830N
	M b di 59Nm	M b peak 140Nm	M b max 239Nm
LHD-17	F t di 330N	Ft peak 570N	Ft max 990N
	F a di 330N	F a peak 570N	F a max 990N
	M b di 117Nm	M b peak 230Nm	M b max 468Nm
LHD-20	F t di 550N	Ft peak 975N	F t max 1680N
	F a di 550N	F a peak 975N	F a max 1680N
	M b di 213Nm	M b peak 420Nm	M b max 855Nm
LHD-25	F t di 790N	Ft peak 1400N	F t max 2450N
	F a di 790N	F a peak 1400N	F a max 2450N
LUB 00	M b di 400Nm	M b peak 800Nm	M b max 1600Nm
LHD-32	F t di 1240N	Ft peak 2100N	F t max 3680N
	F a di 1240N	F a peak 2100N	F a max 3680N
LHD-40	M b di 600Nm	M b peak 1200Nm	M b max 2520Nm
LПD -4 0	F t di 1530N	Ft peak 2670N	F t max 4600N
	F a di 1530N	F a peak 2670N	F a max 4600N

[■] Note: Output load Mb- Bending moment, Ft-radial force, Fa-axial force




[■] Note1: Reduction ratio indicates of wave generator as inputting, fixing circular spline, and flexspline as outputting.


LSS series



• Combinative structure of LSS series




Rated parameter table of LSS/LSN series





Model	Reduction ratio	at 200	torque 00r/min put	torque	ible peak at start stop	value fo	le maximum or average torque		e maximum entary que	Permissible maximum input rotational speed(Grease)	Permissible average input rotational speed(Grease)	backlash	Design life
		Nm	Kgfm	Nm	Kgfm	Nm	Kgfm	Nm	Kgfm	r/min	r/min	Arc Sec	Hour
	50	5.4	0.55	18	1.8	6.9	0.70	35	3.6				10000
	80	7.8	0.80	23	2.4	11	1.1	47	4.8	8500	3500	/20	15000
14	100	7.8	0.80	28	2.9	11	1.1	54	5.5	6300	3300	≤20	15000
	120	7.8	0.80	28	2.9	11	1.1	54	5.5				15000
	50	16	1.6	34	3.5	26	2.6	70	7.1				10000
17	80	22	2.2	43	4.4	27	2.7	87	8.9	7300	3500	/20	15000
17	100	24	2.4	54	5.5	39	4.0	108	11	1300	3500	≤20	15000
	120	24	2.4	54	5.5	39	4.0	86	8.8				15000
	50	25	2.5	56	5.7	34	3.5	98	10				10000
	80	34	3.5	74	7.5	47	4.8	127	13				15000
20	100	40	4.1	82	8.4	49	5.0	147	15	6500	3500	≤20	15000
	120	40	4.1	87	8.9	49	5.0	147	15				15000
	160	40	4.1	92	9.4	49	5.0	147	15				15000
	50	39	4.0	98	10	55	5.6	186	19				10000
	80	63	6.4	137	14	87	8.9	255	26	F.C.0.0	2500	≤20	15000
25	100	67	6.8	157	16	108	11	284	29	5600	3500	≪20	15000
	120	67	6.8	167	17	108	11	304	31				15000
	50	76	7.8	216	22	108	11	382	39				10000
20	80	118	12	304	31	167	17	568	58	4000	2500	-20	15000
32	100	137	14	333	34	216	22	647	66	4800	3500	≤20	15000
	120	137	14	353	36	216	22	686	70				15000
	50	137	14	402	41	196	20	686	70				10000
40	80	206	21	519	53	284	29	980	100	1000	2000	-20	15000
40	100	265	27	568	58	372	38	1080	110	4000	3000	≤20	15000
	120	294	30	617	63	451	46	1180	120				15000


Rated parameter table of LSG series


Model	Reduction ratio	at 200	torque 00r/min put	torque	ble peak at start stop	value fo	e maximum r average torque	mon	le maximum nentary rque	Permissible maximum input rotational speed(Grease)	Permissible average input rotational speed(Grease)	backlash	Design life
		Nm	Kgfm	Nm	Kgfm	Nm	Kgfm	Nm	Kgfm	r/min	r/min	Arc Sec	Hour
11	80	3.8	0.4	8.5	0.9	6.8	0.7	19.1	1.9	8000	3000	≤20	10000
	100	4.1	0.4	8.9	0.9	7.2	0.7	20	2	0000	3000	220	10000
	50	7	0.7	23	2.3	9	0.9	46	4.7				
14	80	10	1	30	3.1	14	1.4	61	6.2	10000	6500	≤20	15000
	100	10	1.0	36	3.7	14	1.4	70	7.2				
	50	21	2.1	44	4.5	34	3.4	91	9				
17	80	29	2.9	56	5.7	35	3.6	113	12	7500	5600	≤20	20000
	100	31	3.2	70	7.2	51	5.2	143	15				
	50	33	3.3	73	7.4	44	4.5	127	13				
	80	44	4.5	96	9.8	61	6.2	165	17			≤20	
20	100	52	5.3	107	10.9	64	6.5	191	20	7000	4800		20000
	120	52	5.3	113	11.5	64	6.5	191	20				
	160	52	5.3	120	12.2	64	6.5	191	20				
	50	51	5.2	127	13	72	7.3	242	25				
25	80	82	8.4	178	18	113	12	332	34	5600	4000	≤20	20000
25	100	87	8.9	204	21	140	14	369	38	0000	4000	-20	20000
	120	87	8.9	217	22	140	14	395	40				
	50	99	10	281	29	140	14	497	51				
32	80	153	16	395	40	217	22	738	75	5600	3000	≤20	20000
	100	178	18	433	44	281	29	841	86	2300	2300	≥20	20000
	120	178	18	459	47	281	29	892	91				















Generator's location limited mounting hole





- Please noted that the length of bolt mesh should be kept within the depth of internal thread. If it exceeded symbol i size, the flexspline will be damaged.
 ψE position is through-hole shape which leads to inside of the product. The size of * in figure is reference dimension of installation.please comply with requirements of such installation size.
- The output flange will be different based on each type. For details, please contact our authorized distributor.


*For detailed information of product, please confirm it with delivery specification figure.


ФВ 55 62 70 85 73 73 74 75 75 75 75 75 75 75 75 75 75 75 75 75	113 112 96 26 20 14.2 21.8% 35 90 138 62 57 3 5.3 17 5.5 12 1 36.2
ФС 42.5 49.5 58 73 Ф D H7 11 10 14 20 Ф Е 8 7 10 15 Ф F 9.4 9.5 9 12 G 9.4° 9.5 9 12 Ф H 14 16 22 22 Ф I h7 38 48 56 67 Ф J 73 79 93 107 К 41 45 45.5 52 L 36 37 38 46 M 2 2 2 3 3 3 3 N 4.5 2.5 4 3.5 O 12 12 12 12.5 14 P 4 4 5.5 5.5 Q 7 8 10 10 10 R 0.5 0.5 0.5 0.5 S 21.4 23.5 23 29 T 4.1 2.5 4 3.5 U 15.5° 19.6° 19.	96 26 20 14.2 21.8 ^{-6.1} 35 90 138 62 57 3 5.3 17 5.5 12 1 36.2
Ф В Н7 11 10 14 20 15 4 15 5 15 14 15 15 10 15 10 15 10 15 15 10 15 10 15 10 15 15 10 15 15 10 15 15 10 15 15 10 15 15 10 15 15 10 15 15 10 15 15 15 10 15 15 10 15 15 10 15 15 10 15 15 10 15 15 10 15 15 10 15 15 10 15 15 10 15 15 10 15 15 10 15 15 10 15 15 10 15 15 10 15 15 15 10 15 15 10 15 15 10 15 15 10 15 15 10	26 20 14.2 21.8**** 35 90 138 62 57 3 5.3 17 5.5 12 1 36.2
ФЕ 8 7 10 15 15 12 12 12 12 12 15 14 15 15 15 15 15 15 15 15 15 15 15 15 15	20 14.2 21.8*** 35 90 138 62 57 3 5.3 17 5.5 12 1 36.2
ФЕ 8 7 10 15 15 12 12 12 12 12 12 15 14 15 15 15 15 15 15 15 15 15 15 15 15 15	14.2 21.8**** 35 90 138 62 57 3 5.3 17 5.5 12 1 36.2
Ф F 9.4 9.5 9 12 G 9.4° 14 9.5° 94° 16.3° 16.3° 16.3° 1 Ф Н 14 16 22 22 Ф I h7 38 48 56 67 Ф Ј 73 79 93 107 К 41 45 45.5 52 L 36 37 38 46 M 2 2 2 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3	14.2 21.8**** 35 90 138 62 57 3 5.3 17 5.5 12 1 36.2
G 9.4% 9.4% 9.4% 16.3% 16.3% Φ H 14 16 22 22 Φ I h7 38 48 56 67 Φ J 73 79 93 107 K 41 45 45.5 52 L 36 37 38 46 M 2 2 3 3 N 4.5 2.5 4 3.5 O 12 12 12.5 14 P 4 4 5.5 5.5 Q 7 8 10 10 R 0.5 0.5 0.5 0.5 S 21.4 23.5 23 29 T 4.1 2.5 4 3.5 U 15.5% 19.5% 18.5% 19.5% V 5 6 4.5 6	21.8 ^{+0.1} 35 90 138 62 57 3 5.3 17 5.5 12 1 36.2
Φ H 14 16 22 22 Φ I h7 38 48 56 67 Φ J 73 79 93 107 K 41 45 45.5 52 L 36 37 38 46 M 2 2 3 3 N 4.5 2.5 4 3.5 O 12 12 12.5 14 P 4 4 5.5 5.5 Q 7 8 10 10 R 0.5 0.5 0.5 0.5 S 21.4 23.5 23 29 T 4.1 2.5 4 3.5 U 15.5% 19% 18.5% 19.5% 19.5% V 5 6 4.5 6	35 90 138 62 57 3 5.3 17 5.5 12 1 36.2
Ф I h7 38 48 56 67 Ф J 73 79 93 107 К 41 45 45.5 52 L 36 37 38 46 М 2 2 2 3 3 3 N 4.5 2.5 4 3.5 O 12 12 12 12.5 14 P 4 4 5.5 5.5 Q 7 8 10 10 10 R 0.5 0.5 0.5 0.5 S 21.4 23.5 23 29 T 4.1 2.5 4 3.5 U 15.5 ^α _{α1} 19.5 ^α _{α1} 18.5 ^α _{α1} 19.5 ^α _{α1}	90 138 62 57 3 5.3 17 5.5 12 1 36.2
K 41 45 45.5 52 L 36 37 38 46 M 2 2 3 3 N 4.5 2.5 4 3.5 O 12 12 12.5 14 P 4 4 5.5 5.5 Q 7 8 10 10 R 0.5 0.5 0.5 0.5 S 21.4 23.5 23 29 T 4.1 2.5 4 3.5 U 15.5% 19% 18.5% 19.5% V 5 6 4.5 6	62 57 3 5.3 17 5.5 12 1 36.2
L 36 37 38 46 M 2 2 3 3 N 4.5 2.5 4 3.5 O 12 12 12.5 14 P 4 4 5.5 5.5 Q 7 8 10 10 R 0.5 0.5 0.5 0.5 S 21.4 23.5 23 29 T 4.1 2.5 4 3.5 U 15.5%1 19%1 18.5%1 19.5%1 V 5 6 4.5 6	57 3 5.3 17 5.5 12 1 36.2
L 36 37 38 46 M 2 2 3 3 N 4.5 2.5 4 3.5 O 12 12 12.5 14 P 4 4 5.5 5.5 Q 7 8 10 10 R 0.5 0.5 0.5 0.5 S 21.4 23.5 23 29 T 4.1 2.5 4 3.5 U 15.5%1 19%1 18.5%1 19.5%1 V 5 6 4.5 6	3 5.3 17 5.5 12 1 36.2
M 2 2 3 3 N 4.5 2.5 4 3.5 O 12 12 12.5 14 P 4 4 5.5 5.5 Q 7 8 10 10 R 0.5 0.5 0.5 0.5 S 21.4 23.5 23 29 T 4.1 2.5 4 3.5 U 15.5%1 19%1 18.5%1 19.5%1 V 5 6 4.5 6	3 5.3 17 5.5 12 1 36.2
N 4.5 2.5 4 3.5 O 12 12 12.5 14 P 4 4 5.5 5.5 Q 7 8 10 10 R 0.5 0.5 0.5 0.5 S 21.4 23.5 23 29 T 4.1 2.5 4 3.5 U 15.5%, 19 19%, 19%, 18.5%, 19%, 19%, 19%, 19%, 19%, 19%, 19%, 19	5.3 17 5.5 12 1 36.2
O 12 12 12.5 14 P 4 4 5.5 5.5 Q 7 8 10 10 R 0.5 0.5 0.5 0.5 S 21.4 23.5 23 29 T 4.1 2.5 4 3.5 U 15.5% 19% 18.5% 19.5% V 5 6 4.5 6	17 5.5 12 1 36.2
P 4 4 5.5 5.5 Q 7 8 10 10 R 0.5 0.5 0.5 0.5 S 21.4 23.5 23 29 T 4.1 2.5 4 3.5 U 15.5% 19% 18.5% 19.5% V 5 6 4.5 6	5.5 12 1 36.2
Q 7 8 10 10 R 0.5 0.5 0.5 0.5 S 21.4 23.5 23 29 T 4.1 2.5 4 3.5 U 15.5% 19% 18.5% 19.5% V 5 6 4.5 6	12 1 36.2
R 0.5 0.5 0.5 S 21.4 23.5 23 29 T 4.1 2.5 4 3.5 U 15.5%, 1 19%, 1 18.5%, 1 19.5%, 1 V 5 6 4.5 6	1 36.2
S 21.4 23.5 23 29 T 4.1 2.5 4 3.5 U 15.5° _a , 19° _a , 18.5° _a , 19.5° _a , V 5 6 4.5 6	36.2
T 4.1 2.5 4 3.5 U 15.5\(^0_{a_1}\) 19\(^0_{a_1}\) 18.5\(^0_{a_1}\) 19.5\(^0_{a_1}\) 1 .5 6 4.5 6	
U 15.5% 19% 18.5% 19.5% V 5 6 4.5 6	5.3
V 5 6 4.5 6	20.501
	5
X 27 29 28 36	45
Y 1 1 1.5 1.5	1.5
Z P9 3 3 3 5	6
Φ a H7 8 8 8 14	19
	125
LSS/LSG 8 8 8 10	12
C LSSF 6 6 6 8	12
Φ d 4.5 4.5 5.5 5.5	6.5
LSS/LSG 8 8 8 10	12
e LSSF 6 6 6 10	12
f M4 M4 M5 M5	M6
Φ g 23 27 32 42	55
h 6 6 8 8	8
	M10
	105 x2
	69 x2
Φ I / 12 18 18	26
m / 2 2 2	2
n / M2.5 M2.5 M2.5	2

- The size marked with * symbol refers to the axial connection position and tolerance of three parts, which are wave generator, flexspline, circular spline. The size will have an influence on performance and intensity, therefore, please strictly abide by it.
- There is also difference in tolerance owing to different manufacturing method(casting and machining) for parts and components.
 For size without giving clear indication of tolerance, please contact with our company or authorized distributor if you needed more information.
 Wave generator is individually packaged when delivering the product.










The generator inner hole of type 14and 17 is non-keyway



- Please noted that the length of bolt mesh should be kept within the depth of internal thread. If it exceeded symbol i size, the flexspline will be damaged.
 ψE position is through-hole shape which leads to inside of the product. The size of * in figure is reference dimension of installation, please comply with requirements of such installation size.
- The output flange will be different based on each type. For details, please contact our authorized distributor.
- ${\star} \mathsf{For} \ \mathsf{detailed} \ \mathsf{information} \ \mathsf{of} \ \mathsf{product}, \ \mathsf{please} \ \mathsf{confirm} \ \mathsf{it} \ \mathsf{with} \ \mathsf{delivery} \ \mathsf{specification} \ \mathsf{figure}.$


	Туре	14	17	20	25	32
Symbol						
ФА	h7	56	63	72	86	113
ФЕ	В	55	62	70	85	112
Φ (С	42.5	49 .5	58	73	96
ΦD	H7	11	10	14	20	26
ФІ	E	8	7	10	15	20
ФІ	F	9.4	9.5	9	12	14.2
G		1	1	12.8 0 1	16.3 ^{+0.1} 0	16.3 0 10 10 10 10 10 10 10 10 10 10 10 10 1
ФН	Н	14	18	21	26	26
ΦП	h7	38	48	56	67	90
φ,	J	73	79	93	107	138
К		41	45	45.5	52	62
L		34	37	38	46	57
М		2	2	3	3	3
N		4.5	4.5	4	4.5	5.5
0		7	12	12.5	14	17
Р		4	4	5.5	5.5	5.5
Q		7	8	10	10	12
R		0.5	0.5	0.5	0.5	1
S		21.4	23.5	23	29	36.2
Т		2	2	2.4	2.8	3.8
U		17.6 - 0.1	19.5 -0.1	20.1_01	20.2_0.1	22 - 0.1
V		2	8	7.5	6	5
Х		27	29	28	36	45
Υ		1	1	1.5	1.5	1.5
Z F	P9	1	1	4	5	5
Фа	H7	6	8	11	14	14
ФІ	b	65	71	82	96	125
	LSS/LSG	8	8	8	10	12
С	LSSF	6	6	6	8	12
Ф	d	4.5	4.5	5.5	5.5	6.5
	LSS/LSG	8	8	8	10	12
е	LSSF	6	6	6	8	12
f		M4	M4	M5	M5	M6
Φ (g	23	27	32	42	55
h		6	6	8	8	8
i		M4	M5	M6	M8	M 10
j		50 x2	56 x2	67 x2	80 x2	105 x2
k		29 x 0 .5	34.5x0.8	40.5x1.2	53 x1	69 x2

- The size marked with * symbol refers to the axial connection position and tolerance of three parts, which are wave generator, flexspline, circular spline. The size will have an influence on performance and intensity, therefore, please strictly abide by it.
- There is also difference in tolerance owing to different manufacturing method(casting and machining) for parts and components.
 For size without giving clear indication of tolerance, please contact with our company or authorized distributor if you needed more information.
- Wave generator is individually packaged when delivering the product.

LSD Series



Combinative structure of LSD series





Rated parameter table of LSD series

Model	Model Reduction ratio		Rated torque at 2000r/min input		Permissible peak torque at start and stop		Permissible maximum value for average load torque		e maximum entary que	Permissible maximum input rotational speed(Grease)	Permissible average input rotational speed(Grease)	backlash	Design life
		Nm	Kgfm	Nm	Kgfm	Nm	Kgfm	Nm	Kgfm	r/min	r/min	Arc Sec	Hour
	50	3.7	0.38	12	1.2	4.8	0.49	24	2.4				
14	80	4.2	0.43	16	1.6	5.9	0.6	31	3.1	8500	3500	≤20	7000
	100	5.4	0.55	19	1.9	7.7	0.79	35	3.6				
	50	11	1.1	23	2.3	18	1.9	48	4.9				
17	80	14	1.4	30	0.3	21	2.1	58	5.9	7300	3500	≤20	10000
	100	16	1.6	37	3.8	27	2.8	71	7.2				
	50	17	1.7	39	4.0	24	2.4	69	7.0				
20	80	21	2.1	46	4.7	30	3.1	81	0.8	6500	3500	≤20	10000
	100	28	2.9	57	5.8	34	3.5	95	9.7				


LSD-I series


LSD-14-XX-U-I







LSD-17-XX-U-I












LSD-20-XX-U-I









[■] For detailed information of product, please confirm it with delivery specification figure






Rated parameter table of LFS series


Model	Model Reduction ratio		Rated torque at 2000r/min input		Permissible peak torque at start and stop		Permissible maximum value for average load torque		maximum ry torque	Permissible maximum input rotational speed(Grease)	Permissible average input rotational speed(Grease)	backlash	Design life
		Nm	Kgfm	Nm	Kgfm	Nm	Kgfm	Nm	Kgfm	r/min	r/min	Arc Sec	Hour
	50	3.5	0.4	8.3	0.9	5.5	0.6	17	1.7				
11	80	5	0.5	11	1.1	8.9	0.9	25	2.5	8500	3000	≤20	10000
	100	5	0.5	11	1.1	8.9	0.9	25	2.5				
	50	5.4	0.6	18	1.8	6.9	0.7	35	3.6				
14	80	7.8	0.8	28	2.9	11	1.1	54	5.5	8500	3000	≤20	10000
	100	7.8	0.8	28	2.9	11	1.1	54	5.5				






[■] For detailed information of product, please confirm it with delivery specification figure...

LHT series



Combinative structure of LHT series




Rated parameter table of LHT/LHN series

Model	Reduction ratio		torque at min input	torque at	ble peak start and op	value for a	e maximum overage load rque		e maximum ary torque	Permissible maximum input rotational speed(Grease)	Permissible average input rotational speed(Greaae)	Backlash	Desian life
		Nm	kgfm	Nm	kgfm	Nm	kgfm	Nm	kgfm	r/min	r/min	Arc Sec	Hour
	50	5.4	0.55	18	1.8	6.9	0.70	35	3.6				10000
1.4	80	7.8	0.80	23	2.4	11	1.1	47	4.8	8500	3500	≤20	15000
14	100	7.8	0.80	28	2.9	11	1.1	54	5.5	8300	3300	≪20	15000
	120	7.8	0.80	28	2.9	11	1.1	54	5.5				15000
	50	16	1.6	34	3.5	26	2.6	70	7.1		3500		10000
17	80	22	2.2	43	4.4	27	2.7	87	8.9	7300		≤20	15000
11	100	24	2.4	54	5.5	39	4.0	110	11	1300		≪20	15000
	120	24	2.4	54	5.5	39	4.0	86	8.8				15000
	50	25	2.5	56	5.7	34	3.5	98	10		3500		10000
	80	34	3.5	74	7.5	47	4.8	127	13	6500			15000
20	100	40	4.1	82	8.4	49	5.0	147	15			≤20 ≤20	15000
	120	40	4.1	87	8.9	49	5.0	147	15				15000
	160	40	4.1	92	9.4	49	5.0	147	15				15000
	50	39	4.0	98	10	55	5.6	186	19				10000
25	80	63	6.4	137	14	87	8.9	255	26	5600	3500		15000
25	100	67	6.8	157	16	108	11	284	29	3000	3300	₹20	15000
	120	67	6.8	167	17	108	11	304	31				15000
	50	76	7.8	216	22	108	11	382	39				10000
32	80	118	12	304	31	167	17	568	58	4800	3500	≤20	15000
32	100	137	14	333	34	216	22	647	66		3300	≪20	15000
	120	137	14	353	36	216	22	686	70				15000
	50	137	14	402	41	196	20	686	70				10000
40	80	206	21	519	53	284	29	980	100	4000	3000	≤20	15000
40	100	265	27	568	58	372	38	1080	110	4000	3000	≥20	15000
	120	294	30	617	63	451	46	1180	120				15000

Rated parameter table of LHG series

Model	Reduction ratio		orque at nin input	Permissi torque at sto	start and	value for a	e maximum verage load que		e maximum ary torque	Permissible maximum input rotational speed(Grease)	Permissible average input rotational speed(Greaae)	Backlash	Desian life
		Nm	kgfm	Nm	kgfm	Nm	kgfm	Nm	kgfm	r/min	r/min	Arc Sec	Hour
	50	7	0.7	23	2.3	9	0.9	46	4.7				10000
14	80	10	1.0	30	3.1	14	1.4	61	6.2	8500	3500	≤20	15000
14	100	10	1.0	36	3.7	14	1.4	70	7.2	8500		≪20	15000
	120	10	1.0	36	3.7	14	1.4	70	7.2				15000
	50	21	2.1	44	4.5	34	3.4	91	9			≤20	10000
17	80	29	2.9	56	5.7	35	3.6	113	12	7300	3500		15000
17	100	31	3.2	70	7.2	51	5.2	143	15	1300			15000
	120	31	3.2	70	7.2	51	5.2	112	11				15000
	50	33	3.3	73	7.4	44	4.5	127	13		3500		10000
	80	44	4.5	96	9.8	61	6.2	165	17	6500			15000
20	100	52	5.3	107	10.9	64	6.5	191	20			≤20	15000
	120	52	5.3	113	11.5	64	6.5	191	20				15000
	160	52	5.3	120	12.2	64	6.5	191	20				15000
	50	51	5.2	127	13	72	7.3	242	25			≤ 20	10000
25	80	82	8.4	178	18	113	12	332	34	5600	3500		15000
23	100	87	8.9	204	21	140	14	369	38	3000	3300	≪20	15000
	120	87	8.9	217	22	140	14	395	40				15000
	50	99	10	281	29	140	14	497	51				10000
32	80	153	16	395	40	217	22	738	75	4800	3500	≤20	15000
32	100	178	18	433	44	281	29	841	86	4000	3300	≪20	15000
	120	178	18	459	47	281	29	892	91				15000
	50	178	18	523	53	255	26	892	91				10000
40	80	268	27	675	69	369	38	1270	130	4000	2000	≤20	15000
40	100	345	35	738	75	484	49	1400	143	4000	3000	≥20	15000
	120	382	39	802	82	586	60	1530	156				15000

0-ø P EQS X1-X2(Y1) EQS φ M2 H7 Z1-Z2 EQS (Prevent separation bolt)



■ For detailed information of product, please confirm it with delivery specification figure.


Size chart

Type	14	17	20	25	32
ΦAh6	50	60	70	85	110
ФВ	14	16	22	24	35
ФСН7	8	8	8	14	19
D	28.5 0.1	32.5 -0.1	33.5-0.1	37 ⁰ -0.1	44 -0.1
E	23.5	26.5	29	34	42
F	5	6	4.5	3	2
G	2.4	3	3	3.3	3.6
Н	14.1	16	17.5	18.7	23.4
I	7	7.5	8.5	12	15
J	6	6.5	7.5	10	14
L	15.5 _{-0.1}	19 ⁰ -0.1	18.5 _{-0.1}	19.5 ⁰ .0.1	20.5 -0.1
M1h7	70	80	90	110	142
M2H7	48#	60	70	88	114
ФМ	14	16	22	22	35
0	8	12	12	12	12
ФР	3.5	3.5	3.5	4.5	5.5
ΦR	64	74	84	102	132
T2(Angle)	22.5°	15°	15°	15°	15°
ФU	44	54	62	77	100
V	9.4 0 9.4 0 9.4	9.4 0 0 1	9.4 0.1	16.3 ^{+0.1}	21.8 0 1
WP9	3	3	3	5	6
X1	8 parts in 12 even distributions	16 parts in 20 even distributions	16	16	16
X2	M3×6	M3×6	M3×6	M4×8	M5×10
Y1	3.5×6	3.5×6.5	3.5×7.5	4.5×10	5.5×14
Z1	4	4	4	4	4
Z2	M3×6	M3×6	M3×8	M3×10	M4×16
Φα	36.5	45	54.5	64.5	86
b	1	1	1.5	1.5	2
Фс	31	38	48	58	77
d	1.2	1.7	1.7	1.9	2.1
Фе	1	12	18	18	26
f	1	2	2	2	2
g	1	M2.5	M2.5	M2.5	M3

The size marked with * symbol refers to the axial connection position and tolerance of three parts, which are wave generator, flexspline, circular spline. The size will have an influence on performance and intensity, therefore, please strictly abide by it.

There is also difference in tolerance owing to different manufacturing method(casting and machining) for parts and components.
 For size without giving clear indication of tolerance, please contact with our company or authorized distributor if you needed more information.
 Owing to flexspline can be distorted, please use inwall size greater than φa.b.c and lesser than d in order to prevent it from being in touch with shell.
 Wave generator is individually packaged when delivering the product.
 The size marked # can be customized according to customer's requirement. For more details, please consult with our authorized distributor.

X1-X2(Y1) Even distribution Z1-Z2 EQS





Size chart

Type	14	17	20	25	32
ΦAh6	50	60	70	85	110
ФВ	14	18	21	26	26
ФСН7	6	8	11	14	14
D	28.5-0.1	32.5-0.1	33.5-0.1	37.0.1	44.0.1
E	23.5	26.5	29	34	42
F	5	6	4.5	3	2
G	2.4	3	3	3.3	3.6
Н	14.1	16	17.5	18.7	23.4
I	7	7.5	8.5	12	15
J	6	6.5	7.5	10	14
L	17.6.0	19.5.0.1	20.1.01	20.2 .0.1	22.0.1
M1h7	70	80	90	110	142
M2H7	48#	60	70	88	114
0	8	12	12	12	12
ФР	3.5	3.5	3.5	4.5	5.5
ΦR	64	74	84	102	132
T2(Angel)	22.5°	15°	15°	15°	15°
ΦU	44	54	62	77	100
V	/	1	12.8 0.1	16.3 ^{*0.1}	16.3 ^{+0.1}
WP9	/	/	4	5	5
X1	8 part in 12 even distributions	16 part in 20 even distributions	16	16	16
X2	M3×6	M3×6	M3×6	M4×8	M5×10
Y1	3.5×6	3.5×6.5	3.5×7.5	4.5×10	5.5×14
Z1	4	4	4	4	4
Z2	M3×6	M3×6	M3×8	M3×8	M4×10
Φα	36.5	45	54.5	64.5	86
b	1	1	1.5	1.5	2
ФС	31	38	48	58	77
d	1.2	1.7	1.7	1.9	2.1

- The size marked with * symbol refers to the axial connection position and tolerance of three parts, which are wave generator, flexspline, circular spline. The size will have an influence on performance and intensity, therefore, please strictly abide by it.
 There is also difference in tolerance owing to different manufacturing method(casting and machining) for parts and components.
 For size without giving clear indication of tolerance, please contact with our company or authorized distributor if you needed more information.
- Owing to flexspline can be distorted, please use inwall size greater than φa.b.c and lesser than d in order to prevent it from being in touch with shell.
- Wave generator is individually packaged when delivering the product.
- The size marked # can be customized according to customer's requirement. For more details, please consult with our authorized distributor.

[■] For detailed information of product, please confirm it with delivery specification figure..







■ For detailed information of product, please confirm it with delivery specification figure..

Type	14	17	20	25	32	40
ΦAh7	70	80	90	110	142	170
ФВ	54	64	75	90	115	140
ΦCh7	36	45	50	60	85	100
ΦDh7	74	84	95	115	147	175
ΦEh7	20	25	30	38	45	59
ΦFh7	14	19	21	29	36	46
G	52.5	56.5	51.5	55.5	65.5	79
Н	12	12	5	6	7	8
I	20.5	23	25	26	32	38
J	20	21.5	21.5	23.5	26.5	33
k	6.5	6.5	1	/	/	/
L	9	10	10.5	10.5	12	14
М	8	8.5	9	8.5	9.5	13
N	7.5	8.5	7	6	5	7
ΦΡ(Ρ)	(2.5)	(2.5)	25.5	33.5	40.5	52
Q	3	3	6	6	6	6
R	M3	M3	M3×6	M3×6	M3×6	M4×8
ФЅ	64	74	84	102	132	158
Т	8	12	12	12	12	12
ΦU	3.5	3.5	3.5	4.5	5.5	6.6
ФV	44	54	62	77	100	122
W	8 part in 12 even distributions	16 part in 20 even distributions	16	16	16	16
×	M3×6	M3×6	M3×6	M4×8	M5×8	M6×10
, x	φ3.5×11.5	φ3.5×12	φ3.5×13.5	Ф4.5×15.5	Ф5.5×20.5	Ф6.6×25
ФҮ	36	45	/	/	/	/
Z	55	5.5	/	/	1	/

Owing to different manufacturing method for parts and components.
 For size without giving clear indication of tolerance, please contact with our company or authorized distributor if you needed more information.








■ For detailed information of product, please confirm it with delivery specification figure.	 owing to different manufacturing method for
--	---

Type Symbol	14	17	20	25	32
ΦAh7	70	80	90	110	142
ФВ	54	64	75	90	115
ФСh7	36	45	50	60	85
ΦDh7	74	84	95	115	147
ΦEh6	6	8	10	14	14
F	50.5	56	63.5	72.5	84.5
G	15	17	21	26	26
Н	20.5	23	25	26	32
I	15	16	17.5	20.5	26.5
J	14	16	20	25	25
k	9	10	10.5	10.5	12
L	8	8.5	9	8.5	9.5
М	2.5	3	3	3	5
0	11	12	16.5	22.5	22.5
Р	1	1	8.2 0.1	11.01	11.0.1
Q	0.5	0.5	3-0.025	5 ⁰ -0.03	5-0.03
R	1	1	3-0.025	5.003	5-0.03
S	1	1	M3×6	M5×10	M5×10
ФТ	64	74	84	102	132
U	8	12	12	12	12
ФV	3.5	3.5	3.5	4.5	5.5
ФW	44	54	62	77	100
X	8 part in 12 even distributions	16 part in 20 even distributions	16	16	16
Y	M3×6	M3×6	M3×6	M4×8	M5×8
,	3.5×11.5	3.5×12	3.5×13.5	4.5×15.5	5.5×20.5


owing to different manufacturing method for parts and components.
 For size without giving clear indication of tolerance, please contact with our company or authorized distributor if you needed more information.








Shape of wave generator of all types





Type Symbol	14	17	20	25	32
ΦAh6	50	60	70	80	110
С	52.5	56.5	51.5	55.5	65.5
D1	15.5	15	8	9.5	12
D2	23.5	26.5	29	34	42
D3	13.5	15	14.5	12	12
E1	2.4	3	3	3.6	3.6
E2	14.1	16	17.5	18.7	23.4
E3	7	7.5	8.5	12	15
F	6	6.5	7.5	10	14
ФG	48	60	7.5	88	114
ФН	70	80	90	110	142
ΨH 11	18.5	19.5	18.5	20	29
12				23	24
13	22 12	23.5 13.5	20.5	12.5	12.5
13 J1	2.5	13.5	12.5	12.5	12.5
J2	7	7		6.5	/
J2 J3	7		7		7
		7	7	6.5	
K1	/	1	1	/	1.7
K2	/	/	/	/	12
ΦL1	23	29	34	43	50
ΦL2	20	25	30	40	45
ФL3	20	25	30	38	45
ФL4	14	19	21	29	36
ФМ1	22	28	34	43	50
ФМ2	20	25	30	38	45
ФМ3	1	1		1	42.5
ФМ4	14	19	21	29	36
ΦN1j6	20	25	30	38	45
ΦN2	14.5	19.5	21.5	29.5	36.5
01	10	10	10	10	10
O2	22.5	24.5	19.5	22.5	30.5
O3	20	22	22	23	25
P1	3	3	6	6	6
P2	M3	M3	M3×6	M3×6	M3
Q1	8	12	12	12	12
Q2	3.5	3.5	3.5	4.5	5.5
ΦR	64	74	84	102	132
ФЅ	1	1	25.5	33.5	40.5
ΦU	44	54	62	77	100
V1	8 part in 12 even distributions	16 part in 20 even distributions	16	16	16
V2	M3×5	M3×6	M3×6	M4×8	M5×10
V3	Ф3.5×6	Ф3.5×6.5	Ф3.5×7.5	Ф4.5×10	Ф5.5×14
Φα	36.5	45	54.5	64.5	86
b	1	1	1.7	1.5	2
Фс	31	38	48	58	77
d	1.2	1.7	1.7	1.9	2.1

The size marked with * symbol refers to the axial connection position and tolerance of three parts, which are wave generator, flexspline, circular spline. The size will have an influence on performance and intensity, therefore, please strictly abide by it.

[■] For detailed information of product, please confirm it with delivery specification figure.

There is also difference in tolerance owing to different manufacturing method(casting and machining) for parts and components.
For size without giving clear indication of tolerance, please contact with our company or authorized distributor if you needed more information.

Owing to flexspline can be distorted, please use inwall size greater than φa.b.c and lesser than d in order to prevent it from being in touch with shell.

Wave generator is individually packaged when delivering the product.

LHD serie

LHD series' flexspline with flanging ultra short tube structure. Which can be used when circular spline fixed, and the flexspline as end output. It can also used to fix the flexspline, and the circular spline as end output. The axial length of LHD-I is shortened by 50%, LHD-III is shortened by 15%, without changing product performance.

Application

Industrial robot


Humanoid robot

Semiconductor manufacturing equipment

FPD manufacturing equipment

Space equipment


Combinative structure of LHD series



Rated parameter table of LHD series

Model	Reduction ratio	Rated torque at 2000r/min input	Permissible peak torque at start and stop	Permissible maximum value for average load torque	Permissible maximum momentary torque	Permissible maximum input rotational speed(Grease)	Permissible average input rotational speed(Greaae)	Backlash	Desian life
		Nm	Nm	Nm	Nm	r/min	r/min	Arc Sec	Hour
	50	3.7	12	4.8	23				9000
14	80	5.1	15	6.2	29	8500	3500	≤20	10000
	100	5.4	19	7.7	35				10000
	50	11	23	18	48				9000
17	80	14	29	21	54	7300	3500	≤20	10000
	100	16	37	27	71				10000
	50	17	39	24	69				9000
20	80	23	49	28	78	6500	3500	≤20	10000
	100	28	57	34	95				10000
	50	27	69	38	127				9000
25	80	42	91	62	157	5600	3500	≤20	10000
	100	47	110	75	184				10000
	50	53	151	75	268				9000
32	80	79	202	126	350	4000	3000	≤20	10000
	100	96	233	151	420				10000

LHD-I size chart



[•] For detailed information of product, please confirm it with delivery specification figure.

LHD-III size chart

LHD-14-XX-U-III 19 5 LHD-17-XX-U-III LHD-20-XX-U-III 12-Ø3.5 Ø61.4

■ For detailed information of product, please confirm it with delivery specification figure.

SERVICE

Warranty

Regulations of warranty period and warranty scope of Laifual Drive as follows:

Warranty period

Warranty period is the earlier time between one year after delivery or working time of 2,000 hours on condition that it is used in normal assembly state and lubrication condition recorded in product content.

Warranty scope

Our company is responsible for maintenance or replacement of the product when malfunction resulting from manufacturing defect under warranty period. However, following situations are out of warranty scope.

- Damage results from unsuitable operation or illegal use by clients.
- Damage results from modification or repair that is not carried out by our company.
- Damage not caused by the product.
- Damage results from natural disaster and the like but not the responsibility of our company.
 What's more, the warranty mentioned here is only for our product.
 Other loss caused by damage of the product and related man-hour and cost of assembly and disassembly of equipment is out of the scope of our company's responsibilities.

Trademark

The following trademark has been registered in China.



未福谐波® LAIFUXIEBD

Certification







Application









Metal Working Machine

Processing Machines

Measurement. Analytical and Test System

Medical Equipment









Telescopes

Energy

Communication Equipme

Crating and Packaging Machir










pace Equipment

Robots

lumanoid Robots

Glass and Ceramic Manufacturing System









Printing, Bookbinding and Paper

rinted Circuit Board Manufacturing Mac

Aircra

Semiconductor Manufacturing Systems









Flat Panel Display Manufacturing Systems

Wood, Light Metal and Plastic Machine Tools

Paper-making Machine

Optical Machine



Means that improper use or Warning handling could result in a risk of death or serious injury.



Caution

Means that improper use or handling could result in personal injury or loss of property.

Application restriction

This product cannot be used for the following applications:

- Space flight facility
- · Aircraft equipment
- Nuclear power equipment
- · Equipment and apparatus used in domestic homes
- Vacuum equipment

- · Automotive equipment
- · Personal recreation equipment
- · Equipment that directly works on
- human bodies
- · Equipment for transport of humans
- · Equipment for use in a special environment
- Please consult with our authorized distributor in advance for applications mentioned above.
- Fail-safe devices that prevent an accident must be designed into the equipment when the products are used in any equipment that could result in personal injury or damage to property in the event of product failure.

Design Precaution

Be certain to read the catalog when designing the equipment.

Use only in the proper environment

Please ensure to comply with the following environmental conditions:



- Ambient temperature 0-40°C.
- · No splashing of water or oil.
- · Do not expose to corrosive or explosive gas.
- · No dust such as metal powder.

Install the equipment with the required precision



· Please design and assemble parts correctly, to ensure the recommended installation accuracy in the catalog.

• Failure to hold the recommended tolerances may cause problems such as vibration, reduction in life, deterioration of precision and product failure.

Install the equipment properly

- · Carry out the assembly and installation precisely as specified in the catalog.
- · Observe our recommended fastening methods (including bolts used and tightening torques). Improper assembly may cause problems such as vibration, reduction in life, deterioration of precision and product failure in operation.

Use the specified lubricant

- Do not use the lubricant recommended by the company, can reduce the life of the product. Replace the lubricant as recommended.
- The complete units are factory lubricated .Do not mix with other kinds of grease.

Precautions for use:Be sure to read the catalog when operating Please take the product and parts carefully Please do not exceed its allowable torque when used • Please do not use a hammer etc to strike all parts and Please do not exceed allowable maximum torque of first assembly units forcefully. In addition, please make sure moment when exerting torque. Otherwise untight bolt, waggle and damage of buck-up part might be occurred, fissure and scars won't be taken place because of \triangle which will lead to malfunction. falling down etc. Otherwise it will lead to damage. If output shaft is directly linked to articulated arm etc, • The performance cannot be guaranteed when is used there's a chance that it might be damaged because of under the condition of damage. It might lead to failures like damage etc. collision of articulated arm, which the output shaft cannot not be controlled.

Please do not alter matching components



· All components of the product is made out of processing a complete set. Specified properties cannot be guaranteed when using



Please do not disassemble combo products

Disassembling and reassembling the combo product are strictly prohibited. Otherwise, there is no way to regain its original performance.

Usage of lubricating grease

it with other sets.

Installation notes

- An inflammation may be caused if it splashes into eyes. Please wear protective glasses etc when operation in order to keep it from the eyes.
- · An inflammation may be caused if it touches the skin. Please wear protective gloves etc when operation in order to keep it from the skin.
- Please do not devour (diarrhea and vomit etc will be
- Please note do not cut your finger when opening the container. Please wear protective gloves well.
- · Please keep it away from children.

Emergency management

- Once it splashes into eyes, please wash it for 15 minutes with clean water immediately and receive treatment
- Once it touches the skin, please use the water and soap to wash it fully
- Once it's being swallowed, please do not try hard vomiting but immediately receive the doctor's treatment.

Treatment of waste oil and container



• Regulations require the user is in duty bound to carry out treatment method. Please handle it properly according to relevant laws and regulations. When in doubt, please consult the authorized agent first, then handle it correctly.

- · Please do not exert pressure to an empty container. By doing this may cause it fracture.
- · Please do not weld, heat, trepan or trim to the container. Otherwise, it may burn up the residue inside.

Storage methods

- Please seal it tight after used, in order to prevent dusts and moisture etc from mixing in. Avoid direct sunlight.
- As to products with long-term inventory, make sure performance and rust protection.
- For surface treatment, please refer to the delivery figure.

About scrapping



Disposal should be carried out in accordance with the industrial waste standard.

•Please process it in accordance with industrial waste when scrapping.